




User Guide

AUSTRALIA'S FAVOURITE BLIND SYSTEMS




CONGRATULATIONS

*on your investment in Genuine
Ziptrak® Cable-Guided blinds.*

AFTER INSTALLATION

PVC and Sunscreen Mesh blinds have been rolled up for transportation. You may need to leave the blinds down for several days to allow the material to settle.



OPERATION

Ziptrak® blinds are easy and simple to use, providing a smooth glide for years of carefree operation. **If it is difficult to raise or lower your blind for no obvious reason, please contact your Ziptrak® retailer.**

Assist-Crank & Crank

The crank-driven system provides smooth, lightweight, and consistent control of your blind. To operate, attach the crank handle and rotate it clockwise to raise the blind or anticlockwise to lower it. For your safety, always remove the crank handle after use.

Only operate the blind using the supplied crank handle, as other methods may cause damage. Blinds can be left at any height, provided there are no strong or extreme winds.

ROTATE CLOCKWISE
TO WIND UP.





ROTATE ANTICLOCKWISE
TO WIND DOWN.




Avoid rolling up the blind when it is wet

Moisture within the rolled-up blind material may cause mould to form.



Tightening the cable

Over time, the cables on your Ziptrak® Cable-Guided blinds may lose some tension, affecting their appearance. To check, fully retract the blind and press your finger against the center of the cable, and push away from the skin using light to moderate force. The cable should flex outwards no more than approximately 30mm. If it flexes significantly more than this, **contact your installer for assistance. If possible, provide photos or videos of the issue to help your installer assess and resolve it more efficiently.**



WINDY CONDITIONS

Ziptrak® blinds are trusted by thousands of Australian homes and businesses to create enjoyable outdoor living spaces. The strong, robust system is commonly installed in coastal regions and other areas prone to high winds.

In very windy conditions, the blind fabric may move slightly, creating a small flapping motion. This is normal, and your blind can still be operated safely with minimal extra effort. Extra care should be taken when operating motorised Ziptrak® blinds in wind—they should always be supervised while raising or lowering.

For best performance, blinds should be left fully down or fully retracted, as the halfway position is most vulnerable.

During storms, severe weather, or very strong winds, blinds should always be fully retracted.

Proper installation is key to wind performance.

For more guidance, speak with your retailer or visit the Ziptrak® website.

CLEANING

Ziptrak® blinds should be cleaned regularly to remove the build-up of environmental residues. It is recommended that blinds are washed down every 3 months. If you live in a coastal area, your blinds should be washed more often to thoroughly remove sand, salt, dirt and moisture deposits from all areas of the blind.

With correct cleaning and maintenance, Ziptrak® blinds will look great and function properly for years!

Use Swift® outdoor blinds cleaner on your Sunscreen Mesh or Clear PVC blinds.

For more information visit:
www.ziptrak.com.au/swiftee-outdoor-blind-cleaner/



Mesh and PVC blind materials are not Ziptrak® products. Please speak with your Retailer to receive complete care instructions from the relevant Mesh or PVC manufacturer.

Sunscreen Mesh blinds


- **Do not** use bore water or allow bore water sprinkler systems to wet the blind. Never allow petrochemicals or solvents to touch the blind.
- **Do not** use a high-pressure hose to clean the blind.

PVC blinds:

- **Do not** use window cleaning detergents to clean the PVC.
- Never allow bird droppings, dirt or stains to remain on the PVC for long periods of time.
- The PVC surface is highly sensitive to scratching and marks. Always be cautious when cleaning, operating or moving items around PVC blinds.
- Ideally, use a soft, clean cloth to polish and dry the PVC after cleaning and prior to rolling up the blind.
- Do not use a high-pressure hose to clean the blind.

MAINTENANCE

To keep your Ziptrak® blinds looking their best, regular cleaning is recommended. Gently wipe the cables with a soft, dry cloth. In coastal areas, more frequent cleaning is advised to remove environmental buildup, such as chlorides and sulphur compounds, which can affect the appearance over time.



WARRANTY

Please contact your retailer for details on their warranty period and inclusions. Ziptrak® provides a 5-year warranty on all components of the Ziptrak® Cable-Guided system. For questions or concerns about the performance, operation, or maintenance of your blinds, or to request replacement parts, contact your retailer or Ziptrak® Customer Support directly.

Your local Ziptrak® expert